





Spare Parts List

RBRP 200

RBRP-200


Pos	Part number	Quantity	Specification
1	75926	1	Leg construction left
2	75927	1	Leg construction right
3	7025	1	Cylinder
5	9205	2	Nut
6	9203	1	Locking spanner
8	7003	2	Steady link
9	9202-Z	1	Saddle plate
14	9017	4	Snap ring
19	9204	2	Shaft
20	7004	4	Pin
21	7006	1	Yoke
22	7006-01	1	Yoke
23	75848	2	Tab lock plate
24	7022	1	Nut
25	7023	1	Nut
28	7007	4	Pin
30	75798	1	Counterbalance valve
31	9200	1	Non-return valve
34	7011	4	Split bushing
35	9003	4	Split bushing
36	7010	4	Split bushing



Pos	Part number	Specification	Quantity
1	9111	Cylinder casing	1
2	9119	Head bush	1
3	7021	Piston rod protection	1
4	7024	Cover plate	1
5	9200	Non-return valve	1
6	75798	Counterbalance valve	1
7	9259	Piston rod	1
8	7026	Locking wire	1
9	7025	Cylinder	1
10	9211	Piston	1
11	9116	Seal kit cylinder	1
	9201	Seal kit non-return valve	1
	75824	Seal kit counterbalance valve	1



- © Gusella Bakker B.V.
- Nijverheidsweg 6
- 6662 NG Elst (Gld) The Netherlands
- Tel : + 31 481 374757
- Site : www.gusella-bakker.com
- E-mail : info@gusella-bakker.com